

3DPRINTING STOR





MPO-2 MULTI-PURPOSE OCTOCOPTER: CARGO TRANSPORTER





HEY, STAR!

- KEEP AND FOLLOW THIS MANUAL EACH TIME YOU'D LIKE TO BUILD THIS MODEL.
- PROJECT 3D PRINTING TIME: 20H; BUILD TIME: 5H. TIMES ARE ESTIMATED AND WILL VARY BASED ON YOUR PRINTER SETUP AND YOUR SKILL LEVEL.
- MINIMUM BUILD VOLUME 11×6×6" [28×15×15 CM] USING 0.4MM NOZZLE.
- USE CAUTION WHEN GLUING. ENVIRONMENT SHOULD BE CLEAN AND WELL-VENTILATED.
- IN A GROUP/CLASSROOM ENVIRONMENT IT'S BEST TO HAVE SEVERAL 3D PRINTERS OPERATING AT THE SAME TIME; THIS WAY PRINTS TAKE QUICKER TO PRINT. PRE-LOAD EACH PRINTER WITH THE RECOMMENDED FILAMENT COLOR (SEE "FILAMENT COLORS").
- SHARE A PHOTO OF YOUR CREATION AND DON'T FORGET TO TAG IT #3DPRINTINGSTAR.



THIS PRODUCT IS LICENSED TO ITS ORIGINAL PURCHASER AND IS NOT TO BE RESOLD WITHOUT WRITTEN CONSENT FROM 3D PRINTING STAR. LEARN MORE ABOUT LICENSING (3DPRINTINGSTAR.COM/LICENSE) AND GROUP LICENSING (GREAT FOR SCHOOLS). CONTACT US (3DPRINTINGSTAR.COM/CONTACT) WITH ANY QUESTIONS. PLEASE USE AT YOUR OWN RISK.

VISIT WWW.3DPRINTINGSTAR.COM FOR LATEST VERSION OF MANUAL AND FILES. INSTRUCTION MANUAL MAY CHANGE WITHOUT NOTICE. MANUAL RELEASE DATE: 9/11/2021. MANUAL VERSION: 1.0.

CONTENTS





MPO-2 FILAMENT COLORS (10)



ORDER ONLINE: 3DPRINTINGSTAR.COM/MPO-2


YELLOW

TOOLS AND SUPPLIES



ORDER ONLINE: 3DPRINTINGSTAR.COM/SUPPLIES

APPS




8.0











































13 TAKE EXTRA CARE WHILE GLUING LOCK HANDLES TO LOCK PINS. ENSURE THAT THE PIN DOES NOT GET GLUED TO THE DOOR. USE ONLY A TINY DROP OF GLUE ON EACH HANDLE AS SHOWN BELOW.



POSITION OF LOCK PINS



























































TAKE EXTRA CARE WHILE GLUING LOCK HANDLES TO LOCK PINS. ENSURE THAT THE PIN DOES NOT GET GLUED TO THE DOOR. USE ONLY A TINY DROP OF GLUE ON EACH HANDLE AS SHOWN BELOW.



POSITION OF LOCK PINS




















FILAMENT COLORS USED TOOLS & SUPPLIES NEEDED Image: Construction black yellow Image: Construction black yellow<











FILAMENT COLORS




CONSTRUCTION BLACK YELLOW

TOOLS & SUPPLIES



CA GLUE CLIPPERS


































enjoy! :)



For more exciting projects visit <u>3dprintingstar.com</u>

